

VISION LUXO

QUALITY OPTICS | LED TECHNOLOGY

Our range of Vision LUXO bench magnifiers are widely regarded as the best in their class: the world's premier lighted magnification system. With perfect balance, brilliant images and optical excellence, you can see every detail with astonishing clarity. Colors are bright and accurate, and we have models with ultraviolet (UV) illumination and with electrostatic dissipative (ESD) capabilities in a range to cover every application.

Our magnifiers are designed to maximize horizontal and vertical movement. They provide significant horizontal reach and will always stay in the right position without drifting. The arms are balanced by spring systems which ensure smooth and easy positioning.

Performance enhancing features

- ✓ Designed for industrial applications using renowned Luxo arm technology
- ✓ Large, high quality optics, for comfortable and effective viewing
- ✓ Powerful, controllable light output using the latest LED technology
- ✓ ESD & UV variants available for specialist industry requirements
- ✓ 5 year warranty
- ✓ Made in Norway

Customize your bench magnifier to your application by choosing from a variety of different magnifications. Primary lens magnifications range from 3 diopter (1.88x) to 5 diopter (2.25x). Secondary lenses are available for all models in 4 (2x), 6 (2.5x), or 10 (3.5x) diopter.



BenchKam - Camera accessory for Circus and Wave bench magnifiers

Designed for customers who need to capture and share images while working with bench magnifiers, BenchKam helps meet the increasing need for documentation and reporting.



MORE
INFORMATON



Vision
ENGINEERING

VISION LUXO — TECHNICAL INFORMATION



WAVE LED ■ Wave LED ESD

Wave LED UV ■ Wave LED ESD UV

Industrial rectangular lens LED bench magnifier



Circus LED

Large diameter round bench magnifier



KFM LED ■ KFM LED ESD

Multi-purpose industrial bench magnifier



LFM LED G2

Lightweight illuminated bench magnifier

| Model | Light Source | Body Material & Color | Mounting | Optics | Arm Technology & Movement | Timer & Dimming |
|--|---|--|--|---|---|---|
| Wave LED Wave LED ESD Wave LED UV Wave LED ESD UV | 2 x 6W dimmable LED modules. Brightness 4600 lux at 11" (279mm) focal length. 4000°K correlated color temperature (CCT). 80 color rendition index (CRI). | Steel arm, aluminum head in light grey. Wave ESD-Safe steel arm and die-cast aluminum shade, black only. | Edge clamp as standard. Weighted base and other clamps and mounts available. | 3.5 (1.88x) or 5 (2.25x) diopter, 6.7" x 4.4" rectangular crown glass lens. (171mm x 114mm) | Heavy duty internal spring 45" or 30" (1143mm or 762mm) parallel, three-pivot K-arm. | Step dimming 0-50-100%. Selectable left / right illumination. Auto shut-off function. |
| Circus LED | 10W total energy consumption. Brightness 3830 lux at 11" (279mm) focal length. 4000°K correlated color temperature (CCT). 90 color rendition index (CRI). | Steel arm with aluminum head. Fully enclosed neck design. White with black accents. | Edge clamp as standard. | 3.5 (1.88x) or 5 (2.25x) diopter, 6.5" (165mm) diameter crown glass lens. | Heavy duty internal spring 45" (1143mm) parallel, three-pivot arm with 0.75" (19mm) diameter of steel tubing. | Dimming 10-100%. Auto shut-off function. |
| KFM LED KFM LED ESD | 2 x semi-circular 9W LED modules. Brightness 3000 lux at 13" (330mm) focal length. 4000°K correlated color temperature (CCT). 80 color rendition index (CRI). | KFM LED steel arm, aluminum head in light grey. KFM ESD-Safe steel arm and die-cast aluminum shade, black only.. | Edge clamp as standard. Weighted base and other clamps and mounts available. | 3 (1.75x) or 5 (2.25x) diopter, 5" (127mm) crown glass lens. | Heavy duty internal spring 45" or 30" (1143mm or 762mm) parallel, three-pivot K-arm. | LED light modules are dimmable 1-100%. Auto shut-off function. |
| LFM LED G2 | 9W dimmable LED modules. 1750 lux at focal length 13". 4000°K correlated color temperature (CCT). 80 color rendition index (CRI). | Die-cast aluminum housing in light grey. | Edge clamp as standard. Other mounts available. | Optics: 3 (1.75x) or 5 (2.25x) diopter, 5" (127mm) diameter lens. | Internal-spring 30" or 45" parallel, 3 pivot K-arm. | Step dimming 0-50-100%. 9/4 hour shut-off function. |

NOTE: Secondary lenses are available for all models: 4, 6 or 10 diopter STAYS lens can be attached to the primary lens. Weighted base is available for 30" arm models only.



Every model is backed with a 5 year warranty.
Should something go wrong we will send you a brand new model.



+1 (860) 355 3776
+1 (800) 644 7264 (Toll free)



MORE
INFORMATION